Layout:

USB 3.0 A-male connector

8 Slot for different Memory cards

EX-1634

Bedienungsanleitung

Vielen Dank das Sie sich für den EX-1634 USB 3.0 Card Reader entschieden haben. Für die EX-1634 benötigt man keine zusätzlichen Treiber.

Folgende Betriebssystem werden unterstützt:

- Windows 2000 SP4
- Windows 2003
- Windows XP SP3
- Windows Vista
- Windows 7
- Windows 8

- Mac OS 10.4 oder höher

Folgende Speicher-Karten werden unterstützt:

- SD/SDHC/SDXC/Extreme SD/Extreme II SD/Extreme III SD/Ultra SD/Ultra II SD/Ultra II SD P PLUS/SD ULTRA X/ULTRA SPEE SD/SD PRO/SD ELOTE PRO/HS SD/MMC/MMC 4.0/HS MMC/HS RS MMC/RS MMC/RS MMC 4.0/MMC Mobile (benötigt einen Adapter für MINI SD/HS MINI SD).
- MSHG/MS Pro duo/MS MG Pro/MS MG Pro duo/HS MS MG Pro Duo/HS MS Pro duo
- CF I/CF II/CF 3.0/CF 4.0/Extreme III CF/Extreme CF/Ultra II CF/HS CF/XS CF/CF Elite Pro/CF Pro/CF Pro II/IBM MD/Hitachi MD/Magic Stor MD
- Micro SD/Micro SDHC/Micro SDXC
- xD/Xd 1.21
- M2

Layout:

8 Slot für verschiedene Memory Karten

EXSYS

EX-1634

User Manual

Thank you very much that you choice the EX-1634 USB 3.0 Card Reader. The EX-1634 don't need additional driver.

Following Operating System are supported:

- Windows 2000 SP4
- Windows 2003
- Windows XP SP3
- Windows Vista
- Windows 7
- Windows 8

- Mac OS 10.4 oder höher

Following Memory cards are supported:

- SD/SDHC/SDXC/Extreme SD/Extreme II SD/Extreme III SD/Ultra SD/Ultra II SD/Ultra II SD P PLUS/SD ULTRA X/ULTRA SPEE SD/SD PRO/SD ELOTE PRO/HS SD/MMC/MMC 4.0/HS MMC/HS RS MMC/RS MMC/RS MMC 4.0/MMC Mobile (need a Adapter for MINI SD/HS MINI SD).
- MSHG/MS Pro duo/MS MG Pro/MS MG Pro duo/HS MS MG Pro Duo/HS MS Pro duo
- CF I/CF II/CF 3.0/CF 4.0/Extreme III CF/Extreme CF/Ultra II CF/HS CF/XS CF/CF Elite Pro/CF Pro/CF Pro II/IBM MD/Hitachi MD/Magic Stor MD
- Micro SD/Micro SDHC/Micro SDXC
- xD/Xd 1.21
- M2